



# Logitech K750 Keyboard Battery Replacement

How to replace the battery.

Written By: citizen





## TOOLS:

- [Metal Spudger](#) (1)



## PARTS:

- [ML2032 Rechargeable Battery](#) (1)

## Step 1 — Battery



- The battery tray is near the top edge of the bottom side of the keyboard. It is designed to be easy to insert, difficult to remove.

## Step 2



- I used a putty knife to force the tray back out. Just push it into the gap along the bottom, then angle the handle to direct the force of the tip away from the body of the keyboard. A few taps should get you this far.

### Step 3 — Note battery orientation.



- Once you get the "ears" past the edge, just slide the tray the rest of the way out.
- Note the battery type carefully: It is a ML2032, which is rechargeable. It is NOT the same as a CR2032, which is not rechargeable. Putting a CR2032 in here is a recipe for bad things to happen.
- Note the proper orientation (see picture), positive + symbol facing towards bottom. Negative side facing keys. Slide the tray with the new battery back in. The battery can be oriented incorrectly and NOT work.
- If you want to make it easier to remove the battery the next time, you could trim the ears slightly. Or slice some notches in the plastic "springs" to weaken a little.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-06 03:41:45 PM.